

Temporary Power Outlet

INSTALLATION INSTRUCTIONS - RINGLESS METER CAN

■ STEP 1

Remove the ringless meter can cover and disconnect the **Meter**

■ STEP 2

Locate the included **Ground Connector** and install using safety guidelines to meet local code requirements.

■ STEP 3

Locate the included **Low Profile Adapter*** and feed the **Ground Connector** through the adapter before inserting the **Low Profile Adapter** into the meter socket.

*For ring-style meter cans, the **Low Profile Adapter** is not required.

■ STEP 4

Replace the meter can cover, then locate the included **Meter Lock Ring** and loosen the lock screw so that the ring can be loosely attached to the **Low Profile Adapter**.

■ STEP 5

Attach the **Ground Wire** from the **TPO** device to the **Ground Wire** installed into the meter can. With the **Meter Lock Ring** loosened, firmly insert the **TPO** device into the **Low Profile Adapter**'s jaw blades. Tighten the **Meter Lock Ring** to ensure complete insertion.

■ STEP 6

Before reinstalling the Meter, add an optional **Meter Lock Ring** to prevent tampering or removing the **Meter**.



Ground Connector



Meter Lock Ring



Meter Lock Ring

